



## Pump Initiation Board Operation

#### Description

Pump initiation boards are ready for wall mounting in the pump house. Each initiation has a separate test arrangement and connection with a common drain.

#### Material Specification

Marcharopechication			
Pressure Rating	14 bar	25 bar	40 bar
Pipes & Fittings	Galvanised Carbon Steel BS143, BS1387	Galvanised Carbon Steel BS143, BS1387	Stainless Steel
Ball Valves	PN40	PN40	PN40
Pressure Switch	0.7-14 bar	2-28 bar	2-42 bar
Test Pressure	17.5 bar	31.25 bar	50 bar
Pressure Gauge	0-16 bar	0-25 bar	0-40 bar

#### **Jockey Pump leg**


Jockey Pump is classed as a pressure maintenance pump - it is installed to avoid starting one of the main pumps unnecessarily therefor only requires a single switch

1x Variable Pressure Switch (PS1381V)


#### **Duty Pump leg**

Dual pressure switch design with option to test each switch individually as required by BS EN 12845

> 2x Fixed Pressure Switch (PS1381)



outlet



Internal Poly disc restrictor reduces the flow when pressuring the system to prevent damage of the switch

Mounted on polycarbonate board for easier installation

Lockable ball valve to prevent valves being tampered with

Issue B © 2019 Rapidrop


Rapidrop Global Ltd T: +44 (0) 1733 847 510 F: +44 (0) 1733 553 958 e: rapidrop@rapidrop.com w: www.rapidrop.com

supplied with all boards as standard







# Pump Initiation Board Operation



#### Test Procedure

- 1. Close the test valve to prevent draining the sprinkler system
- 2. Open the drain valve to release the pressure in the switch line. This causes the switch to activate the pump.
- 3. After the test has finished reverse the process.





TG:6.02 Issue B 13/02/2019 © 2019 Rapidrop

Rapidrop Global Ltd
T: +44 (0) 1733 847 510 F: +44 (0) 1733 553 958
e: rapidrop@rapidrop.com
w: www.rapidrop.com






# Pump Initiation Board Operation

#### Standard layouts and ordering codes

To comply with BS EN 12845.

#### 2 pump initiation board

1 jockey pump (single variable switch)
1 main pump (fixed double switches)




**Ordering Codes:** 

RDPIB2PBST - 14 bar maximum pressure
RDPIB2PBS25BAR - 25 bar maximum pressure
- 40 bar maximum pressure

#### 3 pump initiation board

1 jockey pump (single variable switch) 2 main pumps (fixed double switches)




Ordering Codes:

RDPIB3PBS25BAR - 25 bar maximum pressure RDPIB3PBS25BAR - 40 bar maximum pressure

#### 4 pump initiation board

1 jockey pump (single variable switch) 3 main pumps (fixed double switches)



### Ordering Codes:

RDPIB4PBS25BAR - 25 bar maximum pressure
- 40 bar maximum pressure








## Pump Initiation Board Operation

Alternative arrangement examples made to suit customer requirements.


#### 1 pump initiation board

1 jockey pump (single variable switch)




#### 2 pump initiation board

1 jockey pump (single variable switch)1 main pump (single fixed switch)



### 3 pump initiation board

1 jockey pump (single variable switch)2 main pump (single fixed switches)



#### 2 pump initiation board

2 main pumps (fixed double switches)

